

KSU Remote Password Reveal / Reset for IPO Partner System

Using an Avaya Digital Telephone (1408 1416 etc...)

The KSU has 2 passwords.

The “**System Password**” which is optional.

It is used to allow Night Service to be turned on and off as well as accessing sensitive programs.

The “**Remote Password**” is used to access to the KSU through the LAN Port using the Manager program.

Check to see if the optional System Password has been set:

Note: At any time you can press the “**Phone/Exit**” button to start over.

Step 1.

Go to Ext 10 See if the SYSTEM Password has been assigned. **This is NOT the Remote Password.**

Leave the handset in the cradle

Press the Soft Key below the LCD where it says the word ***Admin*** once

Press the Soft Key below the LCD where it says the word ***Select*** once

Press the Down Arrow (below the OK button) until you see “**Restriction/Permissions**”

Press the **OK** button

Press the Down Arrow until you see “**Set System Password**”

Press the **OK** button

If the display reads “**Data:---**” then press the “**Phone/Exit**” button.

Your done here. There is no System Password assigned. Continue to Step 2.

If it says anything else, then what follows “**Data:**” is the System Password.

Write it down.....

Press the “**Phone/Exit**” button

Step 2.

Again at Ext 10

Leave the handset in the cradle

Press the Soft Key below the LCD where it says the word ***Admin*** once

Press the Soft Key below the LCD where it says the word ***Select*** once

On the dial key pad, enter **#730 (POUND 7 3 0)**

If the LCD reads

Remote Password:

Enter Sys Password:xxxx

Then enter the System Password you discovered earlier.

If the LCD reads

Remote Password:

Data: (followed by any characters)

Then what follows “**Data:**” is the Remote Password.

Press the “**Phone/Exit**” button

Telquest

If you want to change the **Remote Password**, then:

- Press the Soft Key below the LCD where it says the word ***Clear*** once
- The LCD will read **Data: password**
- On the dial key pad, enter the new **Service User Password**
- Press the Soft Key below the LCD where it says the word ***Enter*** once
- Press the Soft Key below the LCD where it says the word ***Back*** three times
- Press the Soft Key below the LCD where it says the word ***Exit*** once

The **Remote Password** has now been changed

**Telquest
Tech Support**