

Learning

Official Documentation







Mobile Softphone Quick Setup Guide

Mobile Softphone Quick Setup Guide KX-UCMA

Checklist for Installation





- □Setup IP-PT or User AK's
- ☐Setup V-SIPEXT card and User Account







Phone Programming:

- ☐Bind Mobile Softphone AK's
- ■Download App
- ☐ Setup Dial Modifications
- ☐ Setup SIP Settings
- □Option: Install Certificate

Activation Keys







- NS700/700G/1000
 - IP-PT AK available?
- NSX2000
 - User Account available?
 - For single use
 - Normal User
 - For sub-device use
 - Mobile or Advanced User

Mobile Softphone Quick Setup Guide KX-UCMA

Setup V-SIPEXT Card






Parameters:

- Extension Number
- Password
- Phone Location
- Panasonic SIP Phone only

When INS, SIP Phone Type = Mobile Softphone


Bind the AK to the MPR ID

Login to Panacare. Click the Mobile Softphone Registration button



AK with MPR-ID binding KX-UCMA0**





Download the app





From the device, access the appropriate store and search for:

Panasonic Mobile Softphone

Dial Modification


Dial Modification setup for smooth dialing

Minimum digits of CO Line Calls: Allows app to recognize an external phone number. 4 – 10 digits (default: 7)


Delete "(0)": Enable/Disable – used for converting inbound CID from international calls

CO Line Access Number: set desired number

Modification Plan/Adding Number w/o Modifications: Please see the full technical training documentation.



SIP Settings



Enable When Using Mobile Network: On (default)

If set to off, the mobile softphone will only function using Wi-Fi.

SIP Server Address (remote):

This is the global IP address of the MRG function of the PBX.

SIP Server Port (remote):

This is the external port set for the SIP Proxy Server of the PBX.

SIP Server Address (local):

This is the IP Address of the PBX when accessed locally.

SIP Server Port (local):

This is the Port using locally for SIP Extensions

SIP Username:

This is usually the sip extension and Authentication ID.

Password:

This is the password set for the extension in the V-SIPEXT card.

SIP Local Port:

This is the port used locally on the mobile softphone. It is recommended that this be different than 5060.

SIP Registration Valid Term (sec):

This is the interval whereby the mobile softphone will re-register to the PBX.

Transport Layer Protocol:


This is the protocol being used. UDP or TLS.

All settings must match the PBX for the softphone to function.

Option: Using TLS

SIP-TLS connection

Select PBX for SIP-TLS connection



Panasonic

Learning

Official Documentation

