Panasonic NS-700 UC (Voice Mail/Auto Attendant)

Telquest tech Support

How do I change Custom Service Menus on my Panasonic NS-700 Voice Mail System?

1. Press the Intercom button on any telephone then raise the handset and dial 500.

2. When answered dial #6*998 (POUND SIX STAR NINE NINE EIGHT).

3. Enter the Administrators Password, followed by a #. (POUND).

4. Dial 4 to "Modify Message".

5. Dial 3 "Change The Custom Service Menu".

6. Enter 1 for the Day Menu or Enter 2 for the Night Menu.

Follow the prompts to record, listen and save your greeting.

Note:
Custom Service Menu 1 and 2 are the preset default Custom Service Menus.

If you have changed them, then you will need to be sure that you record in the correct locations in Step 6.