Panasonic NS-700 System
No Message Waiting LED
Telquest Tech Support

TelQuest International
973-808-4588

Here are two areas to check if you are not getting the Message Waiting LED's to work.

**Make sure the Voice Mail Extensions are there...**

1. Click here...

2. Mouse over...

3. This will appear...

4. Click here...

Make sure that 592 and 593 are present and INS (In Service)
If they are not, just type them in.

There may be more if you have purchased additional Application Keys..

Page 2

Make sure that "All Calls Go To Mailbox" is DISABLED.

1. Click here...

NS700 | Web Maintenance Console
007.00138

Login as INSTALLER

Users

PBX Configuration

UM Configuration

📁 1.Mailbox Settings
　　1.Quick Setting
　　2.Full Setting
　　3.Auto Configuration
📁 2.Class of Service
📁 3.UM Extension / Trunk Service
📁 4.Service Settings
📁 5.System Parameters
📁 6.H/W Settings
📁 7.System Security

Network Service

Mailbox Settings (Quick Setting)

5. Select a Mailbox...

	Mailbox Number	Extension	First Name	Last Name
☑	101	101		
☐	102	102		
☐	103	103		
☐	104	104		
☐	105	105		
☐	106	106		
☐	107	107		
☐	108	108		
☐	109	109		
☐	110	110		
☐	111	111		
☐	112	112		
☐	113	113		
☐	114	114		
☐	115	115		
☐	116	116		
☐	117	117		
☐	118	118		
☐	119	119		

2. Click here...

3. Click here...

4. Click here...

Page 1 of 2 ▶ ▶| 100 ▼

View 1-100 of 150

OK   Cancel   Apply

5. Click here...

Close Up View...

The screen below will appear...

Basic Setting

Mailbox Parameters

Mailbox Number	: 101
Extension	: 101
First Name	:
Last Name	:
Mailbox Password	: Edit
Mailbox Password (Message Client)	: Edit
Class of Service (Mailbox)	: 1 ▼
Covering Extension	:
Interview Mailbox	:
All Calls Transfer to Mailbox	: No ▼
Call Transfer Sequence (Selection)	: System ▼
Call Transfer Sequence (Other) [0-9 * # D R F T X , ;]	:
No Answer Time (Selection)	: System ▼
No Answer Time (Other) (10-60 s)	: 0

Must be No...

Apply   Cancel