Panasonic Voice Mail System (UM) NS-700
How to change a Custom Service Menu
Telquest Tech Support

Note:

You must EXIT programming with your computer before trying to record.

If you don't, you will get an error message stating that the feature (Recording) is not available at this time...

1. Press the Intercom button on any telephone then raise the handset and dial 500.

2. When answered dial #6*998 (POUND SIX STAR NINE NINE EIGHT)

3. Enter the Administrators Password, followed by a #. (POUND)

4. Dial 4 to "Modify Message"

5. Dial 3 to "Change The Custom Service Menu"

6. Enter the Custom Service Menu Number: 1 for Day Menu or 2 for Night Menu

7. Follow the prompts to record your greeting.