
Assembling the 1400 Series Digital Deskphones



CAUTION:

Be careful to use the correct jack when plugging in the telephone. The jacks are located on the back of the telephone housing and are flanked by icons to represent their correct use.

[Figure 1](#), [Figure 2](#), and [Figure 3](#) show how to connect cords to jacks on the 1400 Series Digital Deskphones. Before installing these telephones, keep in mind the following information:

- All 1400 Series Digital Deskphones are powered from the switch.
- You can connect one DBM32 Button module to the 1416 telephone. The 1416 telephone has a special jack for connecting the DBM32 Button module.

Note:

The DBM32 Button module requires an external power supply (that is, the 1151C power supply). You must order the 1151C power supply separately.