

Page 2

In Programming 10.1

Put all Company A CO Lines in Trunk Group Number 1

Put all Company B CO Lines in Trunk Group Number 2

In Program 10.2

Set all Company A CO Lines to 601

Set all Company B CO Lines to 602

In Program 3.5.1

Click the Member List button

Select 1 : 601 ICD Group 001

Set the phones that you want to ring for Company A

Click OK button

In Program 3.5.1

Click the Member List button

Select 2 : 602 ICD Group 002

Set the phones that you want to ring for Company B

Click OK button