# Avaya IP Office Partner Edition

Setting Lines for PBX Mode

Telquest Tech Support

Note: Pages are numbered but not in order. Print them out and then place in order.

| File | Edit | View | Tools | Help |

Admin Tasks

- System
- User Setup
- Group Management
- Trunks
- SIP Trunk Administration
- ▶ Outbound Call Handling

1. Click Here...

2. Click Here...

3. Click Here...

Modify ARS

◉ ARS Selectors   ○ Dial Numbers

This example shows
4 Analog CO Lines
Assigned to the Dial 9 Group

Double Click Here...

This will be the Dial 9 Group...

ARS Selector Table

	Selector	Type	Details
▶	65	Group Of Lines	Line Appearances = 01 , 02 , 03 , ...
	66	ISDN Standard Call	Local Number = Default
	67	ISDN Number Withheld	Local Number = Number Withheld

Select Lines

Available Lines		Selected Lines
05:PRI	Add >	01:Analog
06:PRI		02:Analog
07:PRI	Add All >>	03:Analog
08:PRI		04:Analog
09:PRI		
10:PRI		
11:PRI	< Remove	
12:PRI	<< Remove All	
13:SIP		

Add the CO Lines you want
to be in the Dial 9 Group...

Go to Page 3

Page 4

There is no way to create or change the
"Class Of Call" designations.

Just use them as you need them.

1. Click Here...

Modify ARS

○ ARS Selectors   ◉ Dial Numbers

2. Click Here...

Dial Numbers Table

	Class Of Call	Number	Outgoing Lines/ARS	
	Local	Default	65	
	National		68	
▶	International			
	Emergency			
	Cell			
	TollFree			

NOTE:Multiple numbers separated by a ',' can be configured for an ARS.

Select Outgoing ARS

Available ARS		Selected ARS
65	Add >	68
66		
67		
	< Remove	
	<< Remove All	

3. Move 68 from here

4. To Here..

Page 3

1. Click Here...

Modify ARS

● ARS Selectors   ○ Dial Numbers

2. Click Here...

ARS Selector Table

	Selector	Type	Details
	65	Group Of Lines	Line Appearances = 06 , 07 , ...
	66	ISDN Standard Call	Local Number
▶	67 ▾	ISDN Number Withheld	Local Nu... ber Withheld

3. Click Here on the "New" icon... It will create Selector 68...

Then you will see this below:

**4. Click here and
Select "Group of Lines"**

ARS Selector Table

	Selector	Type	Details
	65	Group Of Lines	Line Appearances = 05 , 06 , 07 , ...
	66	ISDN Standard Call	Local Number = Default
	67	ISDN Number Withheld	Local Number = Number Withheld
▶	68	Group Of Lines ▾	Line Appearances = **04**

**The "Selector Code" (Pool Group Number)
Will be 8 + the "Selector Code"
Dialing 868 will pick the "Selected Line" (CO 4 in this case)**

Select Lines

Available Lines		Selected Lines
05:PRI	Add >	**04: Analog**
06:PRI		
07:PRI	Add All >>	
08:PRI		
09:PRI		
10:PRI		
11:PRI	< Remove	
12:PRI		
13:SIP	<< Remove All	

Add Analog CO Line

Notes: Dialing 865 on the Intercom will access CO Line 4.

Selector 65 (aka: 865 / aka: 9) is the default selector.
Any lines assigned here will be accessed by dialing 9 or 865.

Selector 68 (aka: 868) is also a selector code.
Any line assigned here will be accessed by dialing 865.

There are 31 available Selectors (68 through 99 , aka; 868 through 899) but there are only 6 "Dial Numbers Tables".

You can also assign "Pool Buttons" to directly access Outside Lines that are pooled together.