# Avaya IP Office Partner Edition

Setting Lines for PBX Mode

Telquest Tech Support

Note: Pages are numbered but not in order. Print them out and then place in order.

1. Click Here...

2. Click Here...

3. Click Here...

This example shows
8 PRI Channels
Assigned to the Dial 9 Group

Double Click Here...

This will be the Dial 9 Group...

ARS Selector Table

	Selector	Type	Details
▶	65 ⌄	Group Of Lines	Line Appearances = 05 , 06 , 07 , ...
	66	ISDN Standard Call	Local Number = Default
	67	ISDN Number Withheld	Local Number = Number Withheld

Select Lines

Available Lines		Selected Lines
01:Analog	Add >	05:PRI
02:Analog		06:PRI
03:Analog	Add All >>	07:PRI
04:Analog		08:PRI
13:SIP		09:PRI
		10:PRI
	< Remove	11:PRI
	<< Remove All	12:PRI

Add the Channels you want
to be in the Dial 9 Group...

Go to Page 3

Page 4

There is no way to create or change the
"Class Of Call" designations.

Just use them as you need them.

1. Click Here...

Modify ARS

○ ARS Selectors   ⊙ Dial Numbers

2. Click Here...

Dial Numbers Table

Class Of Call	Number	Outgoing Lines/ARS
Local	Default	65
National		68
▶ International		
Emergency		
Cell		
TollFree		

NOTE:Multiple numbers separated by a ',' can be configured for an ARS.

Select Outgoing ARS

Available ARS		Selected ARS
65	Add >	68
66		
67		
	< Remove	
	<< Remove All	

3. Move 68 from here

4. To Here..

**Assign Analog CO Lines
To an ARS Selector Table (Pool Group)**

1. Click Here...

Modify ARS

◉ ARS Selectors   ○ Dial Numbers

2. Click Here...

ARS Selector Table

	Selector	Type	Details
	65	Group Of Lines	Line Appearances = 05 , 06 , 07 , ...
	66	ISDN Standard Call	Local Number = Default
▶	67	ISDN Number Withheld	Local Number = Number Withheld

3. Click Here on the "New" icon... It will create Selector 68...

Then you will see this below:

4. Select "Group of Lines"

ARS Selector Table

	Selector	Type	Details
	65	Group Of Lines	Line Appearances = 05 , 06 , 07 , ...
	66	ISDN Standard Call	Local Number = Default
	67	ISDN Number Withheld	Local Number = Number Withheld
▶	68	Group Of Lines	Line Appearances = 01 , 02 , 03 , ...

**The "Selector Code" (Pool Group Number)
Will be 8 + the "Selector Code"
Dialing 868 will pick one of the "Selected Lines"**

Select Lines

Available Lines		Selected Lines
05:PRI		01:Analog
06:PRI	Add >	02:Analog
07:PRI		03:Analog
08:PRI	Add All >>	04:Analog
09:PRI		
10:PRI		
11:PRI	< Remove	
12:PRI		
13:SIP	<< Remove All	

**Add Analog CO Lines
In the order to be picked...**

Notes:

Selector 65 (aka: 865 / aka: 9) is the default selector.
Any lines assigned here will be accessed by dialing 9 or 865.

There are 31 available Selectors (68 through 99 , aka; 868 through 899) but there are only
6 "Dial Numbers Tables".

You can also assign "Pool Buttons" to directly access Outside Lines that are pooled together.