


Avaya IP Office Standard Essential KSU

Adjusting the Audio Gains Control


Telquest Tech Support




1. Click here...

2. Select the first Analog trunk...

3. Click here...





You will need to change the Gains on EACH of the Analog Trunks.

A>D is the audio level coming into the KSU from the service provider.

D>A is the audio level going out of the KSU to the service provider.

You can try different negative values to see what works best.

