

# Avaya IP Office Standard Mode

## Flexible Call Forward to Outside Number

### Telquest Tech Support

Put a "Fwd Number" Button on the phone... This is used to enter your cell phone number...

1. Click Here...

2. Select User...

3. Click Here...

4. Double Click on a Spare Button...

Button No.	Label	Action	Action Data
1		Appearance	a =
2		Appearance	b =
3		Appearance	

5. Label it...

6. Click Here...

7. Navigate to Here and Click...

8. Click Here...

Add a “Fwd On/Off” button to the phone...

1. Double Click on a Spare Button...

Al Adams: 201*			
User	Voicemail	DND	Short Codes
Button No.	Label	Action	Action Data
1		Appearance	a =
2		Appearance	b =
3	Fwd Number	Forward Number	
4			


2. Label it...

Edit Button

Button No. 4

Label Fwd On-Off

3. Click Here...



4. Navigate to Here and Click...

4

Fwd On/Off

Dial

Group

User

Emulation

Advanced

Appearance

Busy

Call

Dial

Do Not Disturb

Extension

Follow Me

Forward

Hold

Hunt Group

Miscellaneous

Relay

Set

Suspend

Voicemail

Forward Busy Number

Forward Hunt Group Calls Off

Forward Hunt Group Calls On

Forward Number

Forward On Busy Off

Forward On Busy On


Forward On No Answer Off

Forward On No Answer On

Forward Unconditional Off

Forward Unconditional On

5. Click Here...



## Operation

Setting the Fwd Number works differently on different model telephones.

It works best when you use 9508 telephones.

How to enter your cell phone number:

Press the “Fwd Number” button

Enter your Dial Prefix number (what you dial to make an outside call) followed by your cell phone number.

Then press “Done” or “Save” button in the LCD area.

How to turn forwarding On/Off

Press the “Fwd On/Off” button.

The LED will turn on to indicate that calls are forwarded

OR

The LED will turn off to indicate that calls are not forwarded

If you are using Analog CO Lines, be sure to Allow Analog Trunk to Trunk Connect on EACH CO Line....

