


Avaya IP Office Standard Mode Release 8 and Higher Whisper Page Setup Telquest Tech Support




Page 2
We are now working in the USER that will be Originating the Whisper Page:






Page 3



Now, do this in **each** User that you want to be able to Receive a Whisper Page:



Operation:

If v	ou are	using	a "Whis	per Page"	button of	n your phone	
------	--------	-------	---------	-----------	-----------	--------------	--

Press the "Whisper Page" button BEFORE raising your handset.

Now dial the extension number that you want to make the "Whisper Page" to.

There is no Alert Tone heard by anyone.

You can now raise your handset or use your speakerphone to make a One Way Page.

If you are dialing the "Whisper Page" Short Code (*56 and Extension Number)

Raise your handset or press your Speakerphone button.

Press one of the Intercom Buttons. (a= b= c=)

Now dial the extension number that you want to make the "Whisper Page" to.

There is no Alert Tone heard by anyone.

You can now raise your handset or use your speakerphone to make a One Way Page.

Remember:

"Whisper Page" is a ONE WAY PAGE to the extension you are calling.

They cannot speak back to you.

Review:

The number of X's in the Short Code is equal to the number of digits in the systems extensions.

Example:

^{*56}XX is used for 2 digit extensions like 20. 33, 43 etc.

^{*56}XXX is used for 3 digit extensions like 201. 333, 434 etc.

^{*56}XXXX is used for 4 digit extensions like 2201.2 333, 2434 etc.