## SIP Registrar

It cannot be enabled until you create a SIP Extension.

SIP DECT does not count.

It looks like you need to create a dummy SIP Extension and then the SIP DECT Extension.