


# Snom PA1 SIP Page Unit

## Telquest Tech Support

See Page 11 in the Manual to Initialize the Snom PA1 Page Unit Snom PA1



Go to the area below area in the Snom and enter the credentials for this device.

### Configuration Identity 1

VERSION 8

**Operation**

- Home
- Directory

**Setup**

- Preferences
- Speed Dial
- Function Keys
- Identity 1**
- Identity 2
- Identity 3
- Identity 4
- Action URL Settings
- Advanced
- Certificates
- Software Update

**Status**

- System Information
- Log
- SIP Trace
- DNS Cache
- Subscriptions
- PCAP Trace
- Memory
- Settings

**Manual**

**Extension Info for Snom PA1 Page Unit**

**Login Information:**

Identity active: ☒ On ☐ Off ?

Displayname: 333 ?

Account: / Extension Number 333 ?

Password: ..... ?

Registrar: IP Address of the SIP Server / KSU ?

Outbound Proxy: None ?

Failover Identity: 333 ?

Authentication Username: ?

Mailbox: ?

Ringtone: Ringer 1 ?

Custom Melody URL: ?

Display text for idle screen: ?

Ring After Delay (sec): ?

Record Missed Calls: ☒ On ☐ Off ?

Record Dialed Calls: ☒ On ☐ Off ?

Record Received Calls: ☒ On ☐ Off ?

Identity is hidden: ☐ On ☒ Off ?

Apply Re-Register Play Ringer

Remove Identity Remove All Identities

**snom**  
VoIP phones

Set the Network values for the PA1 Page unit.

## Advanced Settings

VERSION 8

**Operation**

Home

Directory

**Setup**

Preferences

Speed Dial

Function Keys

Identity 1

Identity 2

Identity 3

Identity 4

Action URL Settings

**Advanced**

Certificates

Software Update

**Status**

Network
Behavior
Audio
SIP/RTP
QoS/Security
Update

**Network:**

DHCP: ☐ on ☒ off ? Set to OFF...

Options on DHCP: on 1 3 4 6 12 15 42 43 51 66 67 1 ?

Options on DHCP: off 43 120 125 ?

IP address: 192.168.111.66 ?

Netmask: 255.255.255.0 ?

Host Name: snom300-33SD2D ?

IP Gateway: 192.168.111.1 ?

**DNS:**

Domain: ?

DNS Server 1: 192.168.111.1 ?

DNS Server 2: ?

This will be the IP Address, Subnet Mask and ROuter used by the PA1

Set to Auto Answer

## Preferences

VERSION 8

**Operation**

Home

Directory

**Setup**

**Preferences**

Speed Dial

Function Keys

Identity 1

Identity 2

Identity 3

Identity 4

Action URL Settings

Advanced

Certificates

Software Update

**Status**

System Information

Log

SIP Trace

DNS Cache

Subscriptions

PCAP Trace

Memory

Settings

**Manual**

**General Information:**

Webinterface Language: English ?

Language: English ?

Number Display Style: Name ?

Tone Scheme: Australia ?

MWI Notification: Silent ?

MWI Dial Tone: Stutter ?

Use Headset Device: RJ connector ?

Use Backlight: on ?

Dim after (in seconds): 20 ?

U.S. date format (mm/dd): ☐ on ☐ off ?

24 Hour clock: ☐ on ☐ off ?

Show Clock: ☐ on ☐ off ?

U.S. dialnumber format: ☐ on ☐ off ?

Use Flash Plugin: ☐ on ☒ off ?

Redundant Softkeys: ☐ on ☒ off ?

Show IVR digits during connected: ☐ on ☒ off ?

Global counter for Missed Calls: ☐ on ☐ off ?

Active Identity Scrolling: ☐ on ☐ off ?

Scroll step interval: 400 ?

Scroll step pause: 4 ?

Show identity index: ☐ on ☒ off ?

Show call status info: ☐ on ☒ off ?

Advertisement: ☐ on ☐ off ?

**PA1 Controls:**

Use reset button for dialing: ☐ on ☒ off ?

Phone ends call after set seconds: 300 ?

Scroll Down

**Auto Answer:**

Auto Answer Indication: ☒ on ☐ off ? Set to ON...

**snom**  
VoIP phones

## Set the Amplifier Gain

**Operation**

- Home
- Directory

**Setup**

- Preferences**
- Speed Dial
- Function Keys
- Identity 1
- Identity 2
- Identity 3
- Identity 4
- Action URL Settings
- Advanced
- Certificates
- Software Update

**Status**

- System Information
- Log
- SIP Trace
- DNS Cache
- Subscriptions
- PCAP Trace
- Memory
- Settings

**Manual**

**General Information:**

Webinterface Language: English ?

Language: English ?

Number Display Style: Name ?

Tone Scheme: Australia ?

MWI Notification: Silent ?

MWI Dial Tone: Stutter ?

Use Headset Device: RJ connector ?

Use Backlight: on ?

Dim after (in seconds): 20 ?

U.S. date format (mm/dd): ☐ on ☐ off ?

24 Hour clock: ☐ on ☐ off ?

Show Clock: ☐ on ☐ off ?

U.S. dialnumber format: ☐ on ☐ off ?

Use Flash Plugin: ☐ on ☒ off ?

Redundant Softkeys: ☐ on ☒ off ?

Show IVR digits during connected: ☐ on ☒ off ?

Global counter for Missed Calls: ☐ on ☐ off ?

Active Identity Scrolling: ☐ on ☐ off ?

Scroll step interval: 400 ?

Scroll step pause: 4 ?

Show identity index: ☐ on ☒ off ?

Show call status info: ☐ on ☒ off ?

Advertisement: ☐ on ☐ off ?

**PA1 Controls:**

Use reset button for dialing: ☐ on ☒ off ?

Phone ends call after set seconds: 300 ?

Speaker Volume (1-14): 5 ?

Amplifier Gain : 3 ?

Speaker : ☒ on ☐ off ?

Pin 1: ☐ on ☒ off ?

**snom**  
VoIP phones

© 2000-2012 [snom AG](#)

### Operation:

Once the Snom PA1 is registered to your SIP Server / KSU, just dial the Extension Number that you assigned to it.

You should hear a short beep when you are connected.

Consult the Manual for Audio Connections.