

## Caller ID Common Log Setup for Phones Panasonic KXTA-824

Caller Common Log and Auto Log Method:

**Voicesonic.com**

Go to **EACH TELEPHONE** in the system:

Leave the handset in the cradle.

Press the INTERCOM button. (INT on KXTD 7896 cordless)

**Dial 7382# (7382 POUND)**

Pick up and hang up handset (Press TALK/SP-PHONE on KXTD 7896 cordless)  
(Phone will now **Automatically Log** all answered calls to Common Log)

---

On any Panasonic Multiline telephone – Press the **PROGRAM** button.

Press any spare button with a light on it that you want to be a  
**COMMON CALLER ID INDICATION** button. (Don't use outside lines)  
Dial **96**.

Press the **AUTO DIAL** button.

Press a different spare button with a light on it that you want to be a  
**COMMON CALLER ID SELECTION** button. (Don't use outside lines)  
Dial **97**.

Press the **AUTO DIAL** button.

Pick up and hang up the handset.

---

The **Caller ID Indication** button lights whenever there is at least one  
**Missed Call** logged. **Answered Calls do not light the Caller ID Indicator.**  
Press the button to see the first record. It stores 300 call records.

The **Caller ID Selection** button will allow you to step through the  
Caller ID records. Press it and then use the Navigation disc Up & Down  
arrows to move through the call records.

# Caller ID Common Log Setup for Phones

## Panasonic KXTA-824

Only Station 101 is allowed to clear ALL the call records:

Leave the handset in the cradle.

Press the INTERCOM button.

Dial **70\*\*# (70 STAR STAR POUND)**

All call records will be erased.

Pick up and hang up the handset.

---

For an Answering Machine to log Caller ID:

**KSU = Telephone System Control Box**

1. Unplug the Answering Machine Jack XX connection **at the KSU**.
2. Plug a multi-line telephone in its Jack XX position **at the KSU**.
3. Follow the steps listed above.
4. Re-connect the Answering Machine.

---

Caller ID Name or Number in LCD for KXT 7730 and KXT 7731 Phones

These are Single Line LCD Display telephones.

Do you want to see the Name or the Number when a call comes in?

Program Number:

**[904] Caller ID Log Priority**

Selects which caller information (Name or Number) is shown first on the display of the PT.

PT= Proprietary Telephone (KXT-7730 7731 etc.)

---

Note:

While viewing the LCD Display.

You can alternate between Name and Number by pressing the **# (POUND)** button on the dial.

---

### **How to Call Back a Number using its Caller ID**

Leave the handset in the cradle

Press the **Caller ID Indication Button** (you programed this earlier)

Use the **Navigation Disk** on the lower right side of the phone to select the number that you want to call back

Press an **OUTSIDE LINE** button

Press the **Caller ID Indication** button again

The number you selected will now be dialed for you