


# Panasonic NS-700

## Call Monitor / Executive Busy Override

### Telquest Tech Support

You must add either or both features to a Class of Service:

I am adding both to Class of Service 5 in this example, yours may be different:



The screenshot shows the Panasonic NS-700 Web Maintenance Console. The left sidebar contains a tree view of configuration options. The main area displays the 'COS Settings' page with a table of Class of Service (COS) settings. Annotations with yellow callouts and red boxes indicate the steps to enable features for a specific COS.

**Annotations:**

- 1. Click Here...** (points to the Home icon in the top right)
- 2. Click Here...** (points to the PBX Configuration icon in the left sidebar)
- 3. Click Here...** (points to the Executive tab in the top navigation bar)
- 4. Click Here...** (points to the 2.System icon in the left sidebar)
- 5. Click Here...** (points to the 1.COS Settings icon in the left sidebar)
- 6. Click Here...** (points to the Executive Busy Override checkbox in the table)
- 7. Select a COS and Enable either or both** (points to the row for COS 5)

**Table Data:**

| COS No. | COS Name | Call Monitor | Executive Busy Override | Executive Busy Override Deny |
|---------|----------|--------------|-------------------------|------------------------------|
| 1       |          | ALL          | ALL                     | ALL                          |
| 2       |          | Disable      | Disable                 | Disable                      |
| 3       |          | Disable      | Disable                 | Disable                      |
| 4       |          | Disable      | Disable                 | Disable                      |
| 5       |          | Enable       | Enable                  | Disable                      |
| 6       |          | Disable      | Disable                 | Disable                      |
| 7       |          | Disable      | Disable                 | Disable                      |
| 8       |          | Disable      | Disable                 | Disable                      |
| 9       |          | Disable      | Disable                 | Disable                      |
| 10      |          | Disable      | Disable                 | Disable                      |
| 11      |          | Disable      | Disable                 | Disable                      |
| 12      |          | Disable      | Disable                 | Disable                      |
| 13      |          | Disable      | Disable                 | Disable                      |
| 14      |          | Disable      | Disable                 | Disable                      |
| 15      |          | Disable      | Disable                 | Disable                      |
| 16      |          | Disable      | Disable                 | Disable                      |

Page 1 of 4. View 1-20 of 64.

Buttons: OK, Cancel, Apply

Assign the extension(s) that is allowed to use the features to the same Class of Service:

In this example, you see that Extension 102 (Big Boss) has been assigned to COS 5.

**NS700 Web Maintenance Console**  
004.30033

Login as INSTALLER

**Extension Settings**

Copy to CLIP Generate

Main Intercept Destination Intercept No Answer Time CLIP UM Option 1 Option 2 Option 3 Option 4 Option 5 Option 6 Option 7 Option 8

| No. | Extension Number | Extension Name (20 characters) | Shelf | Slot | Port  | Port Type     | Telephone Type | User Group | COS | Extension PIN |
|-----|------------------|--------------------------------|-------|------|-------|---------------|----------------|------------|-----|---------------|
| 1   | 101              |                                | 1     | 1    | 1     | DPT           | No Connection  | 1          | 64  | Edit          |
| 2   | 102              | Big Boss                       | 1     | 1    | 2     | DPT           | No Connection  | 1          | 5   | Edit          |
| 3   | 103              |                                | 1     | 1    | DXDP1 | DPT(S-DPT)    | No Connection  | 1          | 1   | Edit          |
| 4   | 104              |                                | 1     | 1    | DXDP2 | DPT(S-DPT)    | No Connection  | 1          | 1   | Edit          |
| 5   | 105              |                                | 1     | 2    | 1     | SLT           | UNKNOWN        | 1          | 1   | Edit          |
| 6   | 106              |                                | 1     | 2    | 2     | SLT           | UNKNOWN        | 1          | 1   | Edit          |
| 7   | 107              |                                | 1     | 2    | 3     | SLT           | UNKNOWN        | 1          | 1   | Edit          |
| 8   | 108              |                                | 1     | 2    | 4     | SLT           | UNKNOWN        | 1          | 1   | Edit          |
| 9   | 109              |                                | 1     | 5    | 1     | S-Hybrid      | UNKNOWN        | 1          | 1   | Edit          |
| 10  | 110              |                                | 1     | 5    | 2     | S-Hybrid      | UNKNOWN        | 1          | 1   | Edit          |
| 11  | 111              |                                | 1     | 5    | 3     | S-Hybrid      | UNKNOWN        | 1          | 1   | Edit          |
| 12  | 112              |                                | 1     | 5    | 4     | S-Hybrid      | UNKNOWN        | 1          | 1   | Edit          |
| 13  | 113              |                                | 1     | 5    | 5     | S-Hybrid(SLT) | UNKNOWN        | 1          | 1   | Edit          |
| 14  | 114              |                                | 1     | 5    | 6     | S-Hybrid(SLT) | UNKNOWN        | 1          | 1   | Edit          |

Page 1 of 1 100 View 1-76 of 76

OK Cancel Apply