

Panasonic NS-700 Conference Group Telquest tech Support

A Conference Group allows a permitted extension (by Class of Service) to initiate a call to all phones in the Conference Group.


There are two options for the Digital and NT extensions in the Conference Group.
They can ring until they pick up the call.

Or.

They can have their speaker phone turned on automatically.

In either case, they must press any digit on their phone to be able to talk while in the conference.

Create the Conference Group



1. Click here...

2. Click here...

3. Click here...

4. Name it

5. Enable it

6. See Note

7. See Note

8. Click here

9. Click here

Conference Group Number	Conference Group Name	Broadcast Mode	Ability to Talk	Automatic Answer	Extension Setting
1	Test Conference	Enable	Enable	Enable	
2		Disable	Enable	Disable	
3		Disable	Enable	Disable	
4		Disable	Enable	Disable	
5		Disable	Enable	Disable	
6		Disable	Enable	Disable	
7		Disable	Enable	Disable	
8		Enable	Enable	Disable	

Page 1 of 1 60 View 1-8 of 8

OK Cancel Apply

Page 2

Note: 6

Enable this if you want to allow members to be able to talk while in the conference.
They will need to press any digit to open the Speech Path.

Note: 7

Enable this if you want the Digital and NT phones to have their speaker phones turned on automatically.
They will need to press any digit to open the Speech Path.

Add Members to the Conference Group

NS700 Web Maintenance Console
008.00055

Login as INSTALLER

Users
PBX Configuration

- 1. Configuration
- 2. System
- 3. Group
 - 1. Trunk Group
 - 2. User Group
 - 3. Call Pickup Group
 - 4. Paging Group
 - 5. Incoming Call Distribution Group
 - 6. Extension Hunting Group
 - 7. UM Group
 - 8. PS Ring Group
 - 9. Conference Group**
 - 10. P2P Group
 - 11. VM(DPT) Group
 - 12. VM(DTMF) Group
- 4. Extension
- 5. Optional Device
- 6. Feature
- 7. TRS
- 8. ARS
- 9. Private Network
- 10. CO & Incoming Call
- 11. Maintenance

Conference Group Member

Member list copy Extension No. Setting

1. Select the Group

Conference Group No.: 1: Test Conference

No.	Dial Number	Extension Name
1	101	Receptionist
2	102	Principal
3	103	Admin Desk
4	105	Single Line Telephon
5	912125551212	External Number
6		
7		
8		
9		
10		
11		
12		
13		
14		
15		
16		

2. Add members

Prefix Code 9 required

Page 1 of 2 20 View 1-20 of 31

OK Cancel Apply

3. Click here...

Note:

If you fail to seize idle CO lines necessary for all members assigned in the conference group, you will hear a reorder tone and cannot make a conference group call.

**There are many different features within the Conference Group.
See the the NS700 Operating Manual for a full explanation.**

Allow extension(s) to originate the Conference:

This is done in the Class of Service settings area.

NS700 Web Maintenance Console
008.00055

Login as INSTALLER

Users

PBX Configuration

- 1.Configuration
- 2.System
 - 1.Date & Time
 - 2.Operator & BGM
 - 3.Timers & Counters
 - 4.Week Table
 - 5.Holiday Table
 - 6.Numbering Plan
 - 7.Class of Service
 - 1.COS Settings**
 - 2.External Call Block
 - 3.Internal Call Block
 - 8.Ring Tone Patterns
 - 9.System Options
 - 10.Extension CID Settings
 - 11.Audio Gain
 - 3.Group
 - 4.Extension
 - 5.Optional Device
 - 6.Feature
 - 7.TRS
 - 8.ARS
 - 9.Private Network

COS Settings

TRS CO & SMDR Assistant Executive Manager PDN/SDN Optional Device & Other Extensions CA Miscellaneous

COS No.	COS Name	Conference Group Call Operation
1	Conference Group	Enable
2		Disable
3		Disable
4		Disable
5		Disable
6		Disable
7		Disable
8		Disable
9		Disable
10		Disable
11		Disable
12		Disable
13		Disable
14		Disable
15		Disable
16		Disable

Page 1 of 4

View 1-20 of 64

OK Cancel Apply

7. Click here...

Note:

I have used Class of Service 1 in this example.

That means that any extension in Class of Service 1 can initiate a Conference Group call.

If you only want certain extensions to initiate Conference Group calls, put them and the Conference Group in a different Class of Service.

To make/answer a conference group call

