


Panasonic NS-700

Set FWD/DND Button LED to Steady

Telquest Tech Support

By default, the FWD/DND Button will Flash when either FWD or DND are activated.

You can change it to a Steady LED.



NS700 Web Maintenance Console
004.42024

Login as INSTALLER

System Options

Option 1 Option 2 Option 3 Option 4 Option 5 Option 6 (CTI) Option 7 Option 8 Option 9

PT LCD

Date **1. Click here...**

☐ Date - Month ☒ Month - Date

Time Display

☒ 12 H ☐ 24 H

2. Click here...

PT Fwd / DND

Fwd LED

☒ On (Solid) ☐ Flash **3. Set like this...**

DND LED

☒ On (Solid) ☐ Flash **4. Set like this...**

Fwd/DND key mode when Idle

☒ FWD/DND Setting Mode ☐ FWD/DND Cycle Switch

Paging to DND Extension

☒ Do Not Page ☐ Page

Extension Status of Mobile Integration (FWD NA to CO)

☒ Idle ☐ Busy

PT Operation

Off Hook Monitor

☒ Enable ☐ Disable

Privacy Release by SCO key

☒ Enable ☐ Disable

One-touch Busy Override by SCO key

☐ Enable ☒ Disable

JOG Dial Speed

☐ Normal ☐ High Speed

PT Ring Off Setting

☒ Enable ☐ Disable

Automatic Answer for Call from CO after

☐ No Ring ☒ 1 Ring ☐ 2 Rings ☐ 3 Rings

Automatic Hold by ICM / CO / ICD Group Key

☐ Enable ☒ Disable (Disconnect)

Hold key mode

☒ Hold ☐ Exclusive Hold

OK Cancel Apply **5. Click here...**