


Panasonic NS-700 Disable Missed Call in LCD Telquest Tech Support

You can stop the “Missed Call: 001” from appearing in the LCD of the phones.

This is a System Wide setting so it affects all phones.



1. Click here...

2. Click here...

3. Click here...

4. Click here...

5. Set like this...

For an Individual phone:

In the System Programming...

Go to 4.1.1, Tab 7 and change Incoming Call Log to 0