


Panasonic NS-700

Block Voice Mail From Calling Out Telquest Tech Support



The screenshot shows the 'Web Maintenance Console' for a Panasonic NS-700 system. The left sidebar contains a tree view with categories like 'Users', 'PBX Configuration', 'UM Configuration', 'Mailbox Settings', 'Class of Service', 'UM Extension / Trunk Service', 'Service Settings', 'System Parameters', 'H/VV Settings', 'System Security', and 'Network Service'. The 'Parameters' category is selected, and the 'External Message Delivery' sub-tab is active. The main area displays various settings with numerical input fields and checkboxes. Annotations with red arrows point to specific elements:

- 1. Click here...** points to the 'Parameters' tab.
- 2. Click here...** points to the 'System Parameters' category in the sidebar.
- 3. Click here...** points to the 'Parameters' category in the sidebar.
- 4. Click here...** points to the 'Busy Delay (min)' input field.
- 5. Uncheck both...** points to the checkboxes for extensions 592 and 593.
- 6. Click here...** points to the 'OK' button at the bottom right.

The settings above will disallow the Voice Mail to make any outbound calls.

Voice Mail to Email (if used) will still work.