

**Panasonic NS-700 & NS-700G
Check/Control UM Ports
Telquest Tech Support**

The screenshot shows the 'Web Maintenance' utility for the NS700. The interface includes a left sidebar with navigation options: Status, 1.Equipment Status, 1.UPS, 2.CS Information, 3.PS Information, 4.UM Port Status (highlighted), and 5.USB. The main content area is titled 'UM Port Status' and contains a table with 20 rows. The first two rows show 'Online (Ready)' status, while the remaining 18 rows show 'Off Line'. Five yellow callout boxes with red arrows point to specific elements: '1. Click here...' points to the 'Tools' icon in the top right; '2. Click here...' points to the 'Status' link in the left sidebar; '3. Click here...' points to the 'Web Maintenance' title bar; '4. Click here...' points to the '4.UM Port Status' link in the left sidebar; and '5. Ports Online...' points to the first two rows of the table.

Port	Status
1	Online (Ready)
2	Online (Ready)
3	Off Line
4	Off Line
5	Off Line
6	Off Line
7	Off Line
8	Off Line
9	Off Line
10	Off Line
11	Off Line
12	Off Line
13	Off Line
14	Off Line
15	Off Line
16	Off Line
17	Off Line
18	Off Line
19	Off Line
20	Off Line

Page 1 of 1 30 View 1-24 of 24 Close

Note:

This shows the default Ports 1 & 2 Ready.

You may have purchased Activation Keys for additional Ports in your system.

You can also see the Port Status and turn them on or off here:

1. Mouse Over..

2. Click here...

1. You can see the Ports here and turn them on and off

Port	Extension Number	Connection
1	592	INS
2	593	INS
3		OUS
4		OUS
5		OUS
6		OUS
7		OUS
8		OUS
9		OUS
10		OUS
11		OUS
12		OUS
13		OUS
14		OUS
15		OUS
16		OUS
17		OUS
18		OUS
19		OUS