

# **Avaya 9508 Telephone Audio Adjustments**

## **Telquest Tech Support**

**There are several settings in the 9508 phone that can adjust the audio.**

**A phone may work better with one or all of these options On or Off.**

**Leave the handset in the cradle.**

**Press the HOME button.**

**Press the Down Arrow button and highlight Advanced Options.**

**Press the OK button.**

**Press the Down Arrow button and highlight Audio.**

**Press the OK button.**

**Press the Down Arrow button and highlight Handset AGC.**

**Press the Change button and change the setting from On to Off or Off to On.**

**Press the Down Arrow button and highlight Headset AGC.**

**Press the Change button and change the setting from On to Off or Off to On.**

**Press the Down Arrow button and highlight Speaker AGC.**

**Press the Change button and change the setting from On to Off or Off to On.**

**Press the Down Arrow button and highlight Echo Canceller.**

**Press the Change button and change the setting from On to Off or Off to On.**

**When you have made your changes, press the Save button.**

**To exit, press the PHONE button.**