


Panasonic NS-700

Forward Calls From an Extension to a Cell Phone

Telquest Tech Support

You must program your phone to send calls to your Cell Phone.

This is done on your telephone



You must allow calls to be forwarded in the Class of Service

This is done in the System Programming

1. Click here...

2. Click here...

3. Click here...

4. Click here...

5. Click here...

6. Click here...

7. Set to Enable...

8. Click here...

COS No.	COS Name	Extension-CO Line Call Duration Limit	Transfer to CO	Call Forward to CO	Account Code Mode	Outgoing CO Call Printout (SMDR)
1		ALL	ALL	ALL	ALL	ALL
2		Disable	Enable	Enable	Option	Enable
3			Enable	Disable	Option	Enable
4		Disable	Enable	Disable	Option	Enable
5			Enable	Disable	Option	Enable
6		Disable	Enable	Disable	Option	Enable
7			Enable	Disable	Option	Enable
8		Disable	Enable	Disable	Option	Enable
9		Disable	Enable	Disable	Option	Enable
10		Disable	Enable	Disable	Option	Enable
11		Disable	Enable	Disable	Option	Enable
12		Disable	Enable	Disable	Option	Enable
13		Disable	Enable	Disable	Option	Enable
14		Disable	Enable	Disable	Option	Enable
15		Disable	Enable	Disable	Option	Enable

Note:

This feature uses 2 of your Outside Lines.

A call comes IN on 1 Outside Line and is Forwarded OUT on a Second Outside Line.

If a Second Outside Line is not available, the call will not be forwarded.

Some Service Providers like Fios and Comcast may cause your Outside Lines to “Lock Up”.

This is because they do not always provide a “Positive Disconnect Signal” that tells the NS-700 to release the lines and make them idle when the forwarded call is completed.